

# Yealink W56H Wireless Handset



## Screen Icons

- Ring volume is 0
- Call forward is enabled
- Keypad is locked
- New voicemail
- Do not disturb is enabled
- Receiver mode on
- Hands-free mode on
- Call hold
- Conference call
- Headset mode on
- Contact
- Call mute

ZiPLY Fiber Confidential

# Yealink W56H Wireless Handset



## Answering a call

Press the button.

Press the button to use the speaker.

## Placing a call

Dial the intended number, then:

Press the button, then press OK.

Press the button to use the speaker.

## Checking voicemail

**Message indicator on the screen indicates messages are waiting at the message center.**

1. Press the button.
2. Using the navigational wheel, select the envelope icon on the screen, then press the **select** soft key.

## Blind transfer

**While on a call**

1. Press the **tran** button to place the call on hold.
2. Enter the extension or 10-digit telephone number you want to transfer to.
3. Press the **tran** button again.

## Warm transfer

**While on a call**

1. Press the **tran** button to place the call on hold.
2. Enter the extension or 10-digit telephone number you want to transfer to, then press the button.
3. When the other party answers, press the **tran** button.

## Ending a call

Press the button.

Press the button to use the speaker.

## Place a call on hold

**While on a call**

1. Press the **option** soft key.
2. Use the navigational wheel and select **hold** then press the **OK** button. The caller will hear hold music.
3. Press the **resume** soft key to resume the call.

## Place a conference call

**While on a call**

1. Press the **option** soft key.
2. Use the navigational wheel and select **conference**, then press the **OK** button.
3. Dial the extension or 10-digit telephone number you want to conference in.
4. When the other party answers, select the **conf** soft key again. All parties are joined on the call.

## View call history

1. Press the **history** soft key when the phone is idle.
2. Use the navigational wheel to scroll to the historical calls you wish to view.
  - All calls
  - Missed calls
  - Placed calls
  - Received calls

## Call forwarding

**To enable call forwarding**

1. Press the **OK** button when the phone is idle.
2. Use the navigational wheel and select **call features**. Then select **call forward**.
3. Select the desired forward type:
  - **Always forward:** Incoming calls are forwarded unconditionally.
  - **Busy forward:** Incoming calls are forwarded when the phone is busy.
  - **No answer forward:** Incoming calls are forwarded if not answered.
4. Using the navigational wheel scroll to the right and select **enabled**.
5. Then enter the desired number you want to forward calls to. Then press the **save** soft key.
6. For **no answer forward**, follow the same steps to enable, but you select the desired ring time to wait before forwarding from the **after-ring time** field.
7. Press the **save** soft key to accept the change.

## Volume adjustment

Press the or of the navigation wheel during a call to adjust the receiver volume of the handset/speaker/headset. Press or when the phone is idle or ringing to adjust the ringer volume.

ZiPLY Fiber Confidential